


Calotte di protezione per portafusibili aperti

Protection covers for fuseholders

Fuseholders, Cartridge Fuses



Impiego - Use

Le calotte di protezione per portafusibili aperti della classe J, R, H e K5 forniscono la protezione al contatto accidentale da parte degli operatori. Le calotte con indicatore mostrano quando il fusibile è intervenuto aiutandone l'individuazione. Per l'installazione, la rimozione e la manutenzione è necessario togliere tensione.

Protection covers for fuseholders Class J, R, H and K5 provide protection against accidental contact by personnel. The protection covers with indicating device show when the fuse is open to help to trouble shoot the system. Turn power off before installing, removing or servicing.

Dati Tecnici - Technical data

Caratteristica - Characteristics	Valore/proprietà - Value/property
Classe di autoestinguenza <i>Self-extinguishing class</i>	UL 94 V0
Portafusibile <i>Fuseholder</i>	Class J, R, H, K5
Riferimenti normativi d'impiego <i>Standards of use</i>	NFPA 70 (NEC), UL 508a, CSA C22.1 (CE Code)

Codifiche e dimensioni - Coding and dimensions

Codice <i>Code</i>	Indicatore <i>Indicating</i>	Portafusibile compatibile <i>Compatible fuseholder</i>
FUH_A000_11	Si - <i>Yes</i>	Class J (600 V, 0 ÷ 30 A), RK K5 H (250 V, 35 ÷ 60 A)
FUH_A000_21	Si - <i>Yes</i>	Class RK K5 H (600 V, 0 ÷ 30 A)
FUH_A000_31	Si - <i>Yes</i>	Class J (600 V, 65 ÷ 100 A)
FUH_A000_41	Si - <i>Yes</i>	Class RK K5 H (250 V, 65 ÷ 100 A)
FUH_A000_51	Si - <i>Yes</i>	Class RK K5 H (600 V, 35 ÷ 60 A)
FUH_A000_61	Si - <i>Yes</i>	Class J (600 V, 35 ÷ 60 A)
FUH_A000_71 *	Si - <i>Yes</i>	Class CC (600 V, 0 ÷ 30 A)
FUH_A000_81	Si - <i>Yes</i>	Class RK K5 H (600 V, 65 ÷ 100 A)
FUH_A000_91	Si - <i>Yes</i>	Class RK K5 H (250 V, 0 ÷ 30 A)
FUH_A000_1	No	Class J (600 V, 0 ÷ 30 A), RK K5 H (250 V, 35 ÷ 60 A)
FUH_A000_2	No	Class RK K5 H (600 V, 0 ÷ 30 A)
FUH_A000_3	No	Class J (600 V, 65 ÷ 100 A)
FUH_A000_4	No	Class RK K5 H (250 V, 65 ÷ 100 A)
FUH_A000_5	No	Class RK K5 H (600 V, 35 ÷ 60 A)
FUH_A000_6	No	Class J (600 V, 35 ÷ 60 A)
FUH_A000_7 *	No	Class CC (600 V, 0 ÷ 30 A)
FUH_A000_8	No	Class RK K5 H (600 V, 65 ÷ 100 A)
FUH_A000_9	No	Class RK K5 H (250 V, 0 ÷ 30 A)

* Certificato UL Recognized

* *UL Recognized*